



G Garden State Laboratories, Inc.

Bacteriological and Chemical Testing

Toll Free 800-273-8901
Telephone 908-688-8900
Fax 908-688-8966
Email: info@gslabs.com
Internet: www.gslabs.com

Main Lab
410 Hillside Avenue
Hillside, New Jersey 07205
NJDEP Lab Cert. #20044

Mathew Klein, M.S., Founder (1916-1996)
Harvey Klein, M.S., Laboratory Director
Jordan B. Klein, B.A., Exec. Vice President
Sharon Ercoliani, B.A., Laboratory Manager

Jersey Shore Lab
54 Main Street
Waretown, New Jersey 08758
NJDEP Lab Cert. #15037

PFC Sampling Guidance

- Wash your hands before opening the bag.
- Pull gloves out of bag and put on your hands.
- Remove the two bottles that are rubber banded together (This is the Field Blank) from the plastic bag.
- Transfer the preserved reagent water into the Field Trip Blank Bottle.
- Discard the original reagent bottle.
- Fill remaining bottles with sample water.
- Complete labels on the bottles.
- Once bottles are labeled, place the bottles with water back into the plastic bag.
- Sampling Complete. Bottles should be kept cool until pick up.